


Notice de montage du bras mural SC061 Pour le séchoir pulseur SC2500

BRAS MURAL SC061



COMPOSITION DU KIT :

- 1 bras articulé



- 1 tube inox



- 1 ensemble de différents accessoires



(n°1) x 1

(n°2) x 1

(n°3) x 1

(n°4) x 1

MONTAGE DU BRAS MURAL

Etape 1 :

Prendre le tube inox et l'insérer dans une extrémité du bras articulé

Etape 2 :

Ouvrir le sac plastique, prendre la pièce n°4 et la glisser sur le tube inox.

Ajuster à la hauteur désirée et serrer la vis en plastique noire.


Pièce n°4

Etape 3 :


Placer la pièce n°1 à l'extrémité du tube inox, chaque pièce nécessite deux vis et deux chevilles pour le mur.

Placer le bras mural à la position désirée, matérialiser les 4 emplacements de perçage, percer le mur et insérer une mèche adaptée au support.

Repositionner le bras mural et le fixer au mur.



Etape 4 :



Placer et serrer légèrement une des vis n°3 à l'extrémité du bras mural (côté pulseur), la vis n°3 devra être placée au point de pivot du bras. Placer le dispositif séchant (à l'aide de l'adaptateur fourni) et le bloquer à l'aide de la goupille n°4.

NETTOYAGE ET ENTRETIEN

Le bras mural ne nécessite aucun entretien particulier : laver à l'eau tiède, utiliser un chiffon humide et un produit lavant doux. Ne pas utiliser de produits non appropriés (ex. solvants, crèmes, graisses, etc.).

MONTAGE DU SUPPORT PIVOTANT



Enlever le cache plastique noir du séchoir-pulseur SC2500. La vis se fixe au centre de la pièce, à l'aide de la clé fournie.



Ensuite mettre la molette de réglage sur le côté pour permettre l'inclinaison du séchoir-pulseur. (Photos non contractuelles)

VIVOG SAS

2 Rue de la Briaudière - CS 40001

37515 BALLAN-MIRÉ CEDEX- FRANCE.

Tél. +33 (0)2 47 73 38 38 - fax. +33 (0)2 47 73 38 48

email : infos@vivog.fr

PI10249




SC2500 Dryer-Blaster wall-mounted arm-Assembly instructions

DRYER-BLASTER SC061



KIT CONTENTS:

- 1 articulated arm



- 1 stainless steel tube



- 1 set of different accessories



(n°1) x 1

(n°2) x 1

(n°3) x 1

(n°4) x 1

ASSEMBLY OF WALL-MOUNTED ARM

Step 1:

Take the stainless steel tube and insert it into one end of the arm.

Step 2:


Open the plastic bag, take the piece n°4 and slide it on the stainless steel tube. Adjust to desired height and tighten the black plastic screw

Pièce n°4


Step 3:

Place the piece n°1 at the end of the stainless steel tube, each piece requires two screws and two wall plugs.

Place the wall-mounted arm to desired position, materialize the four locations to drill, drill the wall and insert a plug adapted to support. Reposition the wall-mounted arm and fix on the wall.



Step 4:



Place and slightly tighten screw n° 3 to the end of the wall-mounted arm (blower side), screw n°3 should be at the pivot point of the arm. Place the drying device (using the adapter supplied) and secure with pin n° 4.

CLEANING AND MAINTENANCE

The wall-mounted arm does not require any maintenance: wash with tepid water, use a damp cloth and a soft washing liquid. Do not use inappropriate solvents and aggressive liquids (e.g. cream, greases, etc.).

ASSEMBLY OF THE SWIVEL BRACKET



Remove the black plastic cover from the SC2500 dryer-blaster. The screw must be fixed in the middle of the adapter using the hex key provided.



Then place the adjustment wheel on the side to allow inclination of the dryer-blaster. (non-contractual pictures)

VIVOG SAS

2 Rue de la Briaudière - CS 40001

37515 BALLAN-MIRÉ CEDEX- FRANCE.

Tél. +33 (0)2 47 73 38 38 - fax. +33 (0)2 47 73 38 48

email : infos@vivog.fr

PI10249



3 498551 019010